

Instructions

- HTTP Stream -



Instructions


User Guide of the qube**SERIES** (Software-Version 5.1.1)

- HTTP Stream -

HTTP Stream


Switch on and connect devices:

- Turn on both the Monitor and qubeCONTROL.
- Before you start the simulation, ensure your devices are on the same WiFi network.
- Then open qubeCONTROL, qubeASSESS, and the desired monitor.



Connect devices


- To connect qubeCONTROL and the monitor, tap the red flashing button on the top right corner **Connect Device**.
- Locate your desired monitor and tap on it to select.
- You will be asked to confirm the connection on the monitor. If the devices are successfully connected, a blue frame will appear.



Start Video Stream:

- On qubeCONTROL, navigate to the connection center. Look for the information next to **Video-Stream** on the monitor you want to stream on.
- Enter the IP address (e.g., <http://00.0.00.00:10001>) in a browser of your choice. We recommend Google Chrome. Please make sure the device you like to use to stream the monitor is on the same wireless network as the simulation unit.
- Your Monitor screen should now be displayed on your device's screen.

Note: Only the system monitor is displayed. The buttons on the Monitor are not shown and cannot be operated via the external screen.



Troubleshooting

Problems	Potential causes	Solution
The link doesn't work	The devices are connected to separate Wi-Fi networks.	Please make sure that all devices are connected to the same Wi-Fi.
Weak Wi-Fi connection	Interrupted or weak Wi-Fi connection via the TP-Link Wi-Fi.	Please ensure that the TP-Link is positioned in a location that provides optimal wireless coverage from both the Monitor and the Controller. Too great a distance can lead to a weak connection. Limit the number of connected devices to avoid overloading the Wi-Fi.
The wrong monitor is transmitted	An incorrect Monitor has been connected to the Controller, or a wrong IP address has been entered.	Ensure the correct Monitor is connected to the Controller and the correct IP address has been entered.
IP address is not displayed	The IP address can only be displayed if a Monitor is connected to the Controller.	Try connecting the Monitor to the Controller again.
Controller and Monitor cannot be connected	The app versions do not match.	Check whether updates are available for both apps and install them to ensure both use the same version.

Contact

SKILLQUBE GmbH

Hohenaspen 20
69231 Rauenberg
Germany

info@skillqube.com
www.skillqube.com
+49 6222 38 62 65

